






T360L - PN

**Electronic Weighing Indicator
Technical/User Manual**





Contents

| | |
|--------------------------------------------------|-----------|
| 1 ATTENTIONS | 1 |
| 2 MODEL AND SPECIFICATION | 2 |
| 2.1 FEATURES | 2 |
| 2.2 TECHNICAL SPECIFICATION..... | 2 |
| 2.3 TEMPERATURE AND HUMIDITY..... | 2 |
| 2.4 ENCLOSURE & MOUNTING SIZE | 2 |
| 3 INSTALLATION AND CONNECTION | 4 |
| 3. 1. INSTALLATION..... | 4 |
| 3. 2. WIRING CONNECTION..... | 4 |
| 4 DISPLAY & PANEL | 5 |
| 4.1 KEYPAD..... | 5 |
| 4.2 LED CURSORS | 6 |
| 4.3 VIEW STATISTIC INFORMATION. | 6 |
| 4.4 CLEAR TOTAL STATISTICS..... | 7 |
| 5 SETUP CONFIGURATION | 8 |
| MENU F1 -- SCALE PARAMETERS | 8 |
| MENU F2 -- APPLICATION PARAMETERS: RESERVE..... | 10 |
| MENU F3 -- PLC INTERFACES: RESERVE | 10 |
| MENU F4 -- SERIAL PORTS..... | 10 |
| MENU F5 : RESERVE | 11 |
| MENU F6..... | 11 |
| MENU F7..... | 12 |
| APPENDIX 1 PROMPT OR ERROR MESSAGES | 14 |
| APPENDIX 2 PACKING LIST | 16 |

1 Attentions

Thank you for choosing T360L-PN Electronic Weighing Indicator. For proper application please read this manual carefully before installation.

Check the package be well and make sure the package contents is comply with the packing list.

Check the product model and type is accordance with your order. The product model information is on the label brand above the enclosure.

If there is any parts missed, broken, or model in-conformity in new carton, please prepare the evidence (such as order No., the date of receive goods, product serial No.) and contact our branch office, authorized agency, or service department to deal with.

Ground connection: to ensure the measuring performance and prevent shock hazard, the terminal must be well grounded.

Power supply: This terminal is powered by DC24V.

Environment: This terminal is suitable for industrial use environments. It is not an intrinsic safe terminal and can not be used in hazardous area of explosive dust and gas directly.

2 Model and Specification

T360L-PN weighing controller is designed specially focused on industrial weighing control application. The terminal is equipped with 24-bit $\Sigma-\Delta$ A-D converter, isolated RS232 and RS485 interface. This terminal can be widely used for such as metallurgy, chemical industry fields.

2.1 Features

- * 24 bits high resolution $\Sigma - \Delta$ A-D conversion
- * 1~9 level filter depth
- * Isolated RS232 and RS485 serial interface
- * 6-digits LED display with 0.4' height
- * Standard MODBUS RTU protocol
- * Continuous outputs via RS232 or RS485 for Remote display

2.2 Technical Specification

- * Load cell: 5.0VDC Excitation with 4 parallel 350Ω -analog cells.
- * Load cell sensitivity: $>0.2\mu\text{V}/\text{d}$
- * Linearity: $<0.01\% \text{FS}$


2.3 Temperature and Humidity


Operation temperature: $0^\circ\text{C} \sim 40^\circ\text{C}$, $<85\%$ RH, non-condensation.

Storage temperature: $-20^\circ\text{C} \sim 60^\circ\text{C}$, $<85\%$ RH, non-condensation.

2.4 Enclosure & mounting size

Dimension (Panel, unit: mm): $103.5 \times 56.8 \times 95.2$. Cutout(mm): 46×93






3 Installation and Connection

3. 1. Installation

For Panel mount model, the thickness of mounting door should be less than 2mm and box depth should be over 180mm.

3. 2. wiring Connection

Backplate connection drawing (Panel)



3.2.1. Power connection

For DC model, connect the 24VDC power line with terminal +24V and 0V.

3.2.2. Load cell interface


| Terminal | Description |
|----------|-------------------------------------------------------------------|
| +EXC | positive excitation |
| +SEN | positive senser |
| +SIG | positive signal |
| SHD | shield ground |
| -SIG | negative signal |
| -SEN | negative senser |
| -EXC | negative excitation. short with -SEN if connecting 6-wire cell |

3.2.3. Serial Port

The indicator includes 2 serial ports, one is RS232, one RS485.

| Pin definition | Description | Function |
|----------------|---------------------|--------------------------------------------------------------|
| RXD | RS232 receive data | Continuous output, print output, command output, MODBUS RTU. |
| TXD | RS232 transmit data | |
| COM | Common ground | |
| A+ | RS485 T/R + | Same selections with RS232 port. |
| B- | RS485 T/R - | |

4 Display & Panel



4.1 Keypad

| | | |
|--------------------------------------------------------------------------------------------------------|------------|-------------|
| The T360L-PN panel includes 4 function keys to accomplish basic operation and setting menu navigation. | Definition | Description |
|--------------------------------------------------------------------------------------------------------|------------|-------------|

| | | |
|-----------------------------------------------------------------------------------|------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
| Keypad | | |
| $\rightarrow 0 \leftarrow$ | Zero key | Normal: Short press: zero scale. Long press: Clear total batch & weights. Menu: Return; |
| $\rightarrow T \leftarrow$ | Tare key | Normal: Tare/ Clear tare of the scale. Menu : shift the active edit digit right. |
| C | Select key | Normal: Short press: view statistic qty/weight, tare weight. Long press: Short setpoint editing entry. Menu: scroll selection or increase numeric. |
|  | Enter key | Normal: Long press: Enter into setup menu. Menu : Enter, confirm the selection or number. |

4.2 Led Cursors

| Cursors | Description |
|----------|----------------------------------------------------------------|
| $>0<$ | Current display weight is near center of zero. |
| \sim | Current weight is in motion. |
| NET | Current display weight is net weight with non-zero tare weight |
| BUS | The RS485 comm is active |
| Zero Tol | The weight is under zero tolerance |
| Run | The sequence is running |

4.3 View statistic information.

Press  key to view available information.

【Tare weight】



【Total Counts】



【Total weight】



4.4 Clear total statistics

The display will show **--OF--** if the total statistics grow over flow. The operator can press and hold $\rightarrow 0 \leftarrow$ zero key to reset the statistics data in this condition.



5 Setup Configuration

Note:

To protect the metrological parameters from destroyed by mistake, there is a password entry validation to access the scale capacity, increments, calibration and other sensitive paras.

The fixed password is “2000” . if you are trying to enter F1.1 the password entry will show as below. Do not enter code or incorrect code will cause the terminal skip to next branch menu F2.



Press and hold ENTER key till {F1 } displayed.

In setup menu, press SELECT key to shift next branch menu F2. Press ZERO key to return to upper level.

Menu F1 -- Scale parameters

F1.1 Scale Capacity ----- Default: 10

Range:1 ~ 100000.

the entry value is limited equal or less than 60000 if configure this value via MODBUS.

F1.2 Division value ----- Default: 0.001

0.0001 / 0.0002 / 0.0005 / 0.001 / 0.002 / 0.005 / 0.01 / 0.02 / 0.05 / 0.1 / 0.2 / 0.5 / 1 / 2 / 5 / 10
/ 20 / 50 optional

F1.3 display unit ----- Default: kg

0: kg 1: kN (the decimal point is fixed as 3 in this unit) 2: g

F1.4 Zero Calibration

{E_SCAL }: prompts to empty scale before calibration.

Following the prompts to move loads on the scale then press ENTER key to start sample the empty scale signal. during the calibration, there maybe display any prompt messages. For detailed explanation, please refer to sheet <prompts table> in the end of this manual.

F1.5 Load Calibration

Step 1.

[**dot 2**] In this prompt to select 2-point or 3-point calibration.

[**dot 2**] 2-point capacity calibration.

[**dot 3**] 3-point linearity calibration.

Step 2.

[**LORd**] prompt to add calibration weight WT.

Place weight on the scale and wait till the scale be stable. Press ENTER key entering into load weight input dialog. Input corresponding weight value then press ENTER key to calibrate the added load. In calibrating dialog a number will count down from 10~0.

Step 3. (This step shows only selecting 3-point linearity calibration.)

[**LORd2**] prompt to add second load weight WT2.

Place weight on the scale and wait till the scale be stable. Press ENTER key entering into load weight input dialog. Input corresponding weight value then press ENTER key to calibrate the added load. In calibrating dialog a number will count down from 10~0.

Note: The calibrating unit is fix as kg.

The add load weight should not less than 1% of Capacity (F1.1).

F1.6 filter depth ----- Default:4

Range:0 ~ 8. the bigger the number, the stable the weight.

F1.7 Motion Range ----- Default:OFF.

OFF(no motion detect) / 1d / 2d / 3d / 4d / 5d

F1.8 Over load range ----- Default: 10

9d / 5 / 10 / 20 ($\pm 9d$ / 5%Capacity / 10%Capacity / 20%Capacity)

F1.9 Extended Display ----- Default: OFF

OFF/ON

F1.10 Power-up Zero Range ----- Default: OFF

OFF / 5 / 10 / 20 (disable / 5%Capacity / 10%Capacity / 20%Capacity)

F1.11 Keypad zero range ----- Default: 5

OFF / 5 / 10 / 20 (Disable / 5%Capacity / 10%Capacity / 20%Capacity)

F1.12 Auto Zero Maintain Range ----- Default: OFF

OFF(disable) / 1d / 2d / 3d / 4d / 5d

F1.13 Auto Zero tracking speed----- Default:0.5d

0.5d/1d / 2d / 3d / 4d / 5d (Per second)

- F1.14 Tare key function ----- Default:2
 0:Forbid
 1: Continuous tare
 2:Clear tare
- F1.15 Second filter depth ----- Default:OFF
 Range:OFF,1~6
- F1.16 Traffic update interval ----- Default:OFF
 Range:0~20 (Per 0.1second)
- F1.17 Traffic cycle ----- Default:10
 Range:0~20 (Per 0.1second)

Menu F2 -- Application parameters: Reserve

Menu F3 -- PLC interfaces: Reserve

Menu F4 -- Serial ports

- F4.1 COM1 Baud Rate (RS232) ----- Default: 9600
 600,1200, 2400, 4800, 9600, 19200,38400,57600,115200。
- F4.2 COM1 Data bit (RS232) ----- Default: 8_N
 7_O /7_E /8_N / 8_O/ 8_E
- F4.3 COM1 Stop bit (RS232) ----- Default: 1
 1/1.5/2
- F4.4 COM1 output format (RS232)----- Default: 2
 0: N/A
 1: Continuous output.
 2: MODBUS-RTU
 3: MT Continuous output.
 4: Print output
 5: ASCII Command model
- F4.5 COM1 Node Address (RS232) ----- Default: 11
 Address Range: 1 ~ 254.

- F4.6 COM2 Baud Rate (RS485) ----- Default: 9600
600,1200, 2400, 4800, 9600, 19200,38400,57600,115200。
- F4.7 COM2 Data bit (RS485) ----- Default: 8_N
7_O /7_E /8_N / 8_O/ 8_E
- F4.8 COM2 Stop bit (RS485) ----- Default: 1
1/1.5/2
- F4.9 COM2 output format (RS485)----- Default: 2
0: N/A
1: Continuous output.
2: MODBUS-RTU
3: MT Continuous output.
4: Print output
5: ASCII Command model
- F4.10 COM2 Node Address (RS485) ----- Default: 12
Address Range: 1 ~ 254.
- F4.11 Printout Format ----- Default: 3
1:En narrow row 2:En wide row
3:Cn narrow row 4:Cn wide row
- F4.12 Continuous output cycle ----- Default: 10
Address Range: 1~255. (Per 0.01second)
- F4.13~ F4.17: Reserve

Menu F5 : Reserve

Menu F6

- F6.1 Key protection password ----- Default: Null
The password can be set to 4 digits from 0000 to 9999.
Enter password with Pd prompt, set password with PA prompt.
- F6.2 Scale calibration parameter protection password ----- Default: 2000
The password can be set to 4 digits from 0000 to 9999.
Enter password with Pd prompt, set password with PA prompt.

F6.3 Application parameter protection password ----- Default: Null

The password can be set to 4 digits from 0000 to 9999.

Enter password with Pd prompt, set password with PA prompt.

F6.4 Set AD sample frequency ----- Default: 800

100 / 200 / 400 / 800 / 1600

F6.5 Set display brightness ----- Default: 5

Range:0~7. The larger the number, the brighter the display.

F6.6 Sensor internal code value----- Default: 250

Range:220~65535.

Menu F7

F7.1 Display program version number

F7.2 Display the last change date of the software

F7.3 Key test

F7.4 Serial port 232/485 test

F7.5 : Reserve

F7.6 : Reserve

F7.7 Test Display

Press ENTER key to test display. The display will display from “000000” ~ “999999”. watching the display to make sure if there is any segment is burned.

F7.8 View and Modify calibration parameters

Pd xxxx: Input password. The mismatched password will be denied.

Axxxxxx: Zero point calibration counts.

dxxxxxx: loaded weight point calibration counts.

Exxxxxx: Loaded weight value.

The calibrating data can be view or modified if needed. The operator is suggested to write down the calibration data for reference.

F7.9 Cal-Free operation

Pd xxxx: input access password.

Cxxxxxx: input the total loadcell capacity. E.g. the terminal connect 4 load cells and each load cell's capacity is 100kg. The operator should input the total capacity $100\text{kg} * 4 = 400\text{kg}$.

n 2.000: input the load cell's sensitivity.

【E_SCRL】 : Calibrating empty scale.

F7.10 Easy-to-use calibration

Pd xxxx: Input access password.

E 05.000: Input the estimated load weight.

[LOAD]: Prompt to add load weight on the scale.

L 01.000: Input added weight value.

The easy-to-use calibration completed.

F7.11 Load default parameters

Pd xxxx: Enter password

Enter:

rESEt

All parameters will be restored after confirmation.

Appendix 1 Prompt or Error Messages

| Number | Prompts | Explanations |
|--------|----------|-----------------------------------------------------------------------------|
| 1 | [r----] | Over capacity |
| 2 | [L----] | Under zero |
| 3 | [ad Err] | AD channel initialize failed |
| 4 | [EP Err] | EEPROM Readout error |
| 5 | [EEE] | Power up zero failed for out of positive zero range |
| 6 | [EEE^^^] | Target value too large |
| 7 | [EEE___] | Target value too small |
| 8 | [Err 00] | No application mode set |
| 9 | [Err 01] | Exceeding target tolerance during filling |
| 10 | [Err 02] | Below target tolerance during filling |
| 11 | [Err 03] | Input weight value is too small when calibrating span via communication. |
| 12 | [err 05] | Input weight value is too big when calibrating span via communication. |
| 13 | [Err 06] | The added load weight is too small when calibrating span via communication. |
| 14 | [Err 07] | The scale is in motion when calibration |
| 15 | [Err 08] | Sensor error unable to complete calibration |
| 16 | [E_SCAL] | Prompt to empty scale when calibration |
| 17 | [LOAD] | Prompt to added load when calibration |

| | | |
|----|----------|---------------------------------------------|
| 18 | [--NO--] | Invalid operation. |
| 19 | [--OF--] | The total quantity/weight overflow. |
| 20 | [Print] | When F2.1 not 0,press [ENTER] key will show |

Appendix 2 Packing list

T360L-PN weighing Indicator Packing List

| Number | Product | Model | Qty. | Note |
|--------|-------------------------|----------|------|------|
| 1 | Weighing Indicator | T360L-PN | 1 | |
| 2 | Manual | T360L-PN | 1 | |
| 3 | Certification Card | T360L-PN | 1 | |
| 4 | Power supply terminal | 3.81-3P | 1 | |
| 5 | Load Cell Terminal | 3.81-7P | 1 | |
| 6 | UART and/or DA terminal | 3.81-6P | 1 | |

Package: _____

Check: _____

İZMİR FACTORY
6106/51 SK. NO.1/2 EGEMENLİK MAH. İŞİKKENT BORNOVA/İZMİR
info@tunasistem.com.tr

TEL: 0850 777 88 62 - 0232 281 69 01 FAX: 0232 281 69 01
www.tunasistem.com.tr

İSTANBUL REGIONAL OFFICE

0533 085 33 38
istanbul@tunasistem.com.tr

ANKARA REGIONAL OFFICE

0546 244 33 38
ankara@tunasistem.com.tr

KONYA REGIONAL OFFICE

0546 266 33 38
satis@tunasistem.com.tr

TUNA UZBEKİSTAN OFFICE

998 90 999 08 08
sales@tunasistem.com.tr

BURSA REGIONAL OFFICE

0542 289 33 38
bursa@tunasistem.com.tr

ADANA REGIONAL OFFICE

0546 269 33 38
adana@tunasistem.com.tr

TUNA INDIA OFFICE

91-8130295150
india@tunasistem.com.tr

TUNA QATAR OFFICE

974 5031 5567
qatar@tunasistem.com.tr

CE



İZMİR FACTORY

6106/51 SK. NO.1/2 EGEMENLİK MAH. İŞİKKENT BORNOVA/İZMİR

TEL: 0850 777 88 62 - 0232 281 69 01 FAX: 0232 281 69 01

info@tunasistem.com.tr www.tunasistem.com.tr

İSTANBUL REGIONAL OFFICE

0533 085 33 38
istanbul@tunasistem.com.tr

ANKARA REGIONAL OFFICE

0546 244 33 38
ankara@tunasistem.com.tr

KONYA REGIONAL OFFICE

0546 266 33 38
satis@tunasistem.com.tr

TUNA UZBEKİSTAN OFFICE

998 90 999 08 08
sales@tunasistem.com.tr

BURSA REGIONAL OFFICE

0542 289 33 38
bursa@tunasistem.com.tr

ADANA REGIONAL OFFICE

0546 269 33 38
adana@tunasistem.com.tr

TUNA INDIA OFFICE

91-8130295150
india@tunasistem.com.tr

TUNA QATAR OFFICE

974 5031 5567
qatar@tunasistem.com.tr

TUNA DUBAI OFFICE

971554778170
dubai@tunasistem.com.tr

TUNA SOUTH AFRICA OFFICE

27682699249
south.africa@tunasistem.com.tr

TUNA BULGARİA OFFICE

00 359 877 887 775
sabri.hasan@tunasistem.com.tr

TUNA AZERBAIJAN OFFICE

994 50 685 19 02
sales@tunasistem.com.tr